



NON TOXIC



GERM RESISTANT



PROTECTIVE BARRIER

FILM APPLICATION INSTRUCTIONS

 Sharklet®



1. Wipe surface to be protected with 70% or higher Isopropyl Alcohol (Rubbing Alcohol).
2. Ensure all dust and debris are removed from surface to be covered.
3. To prevent contamination, it is recommended to apply film with gloved hands (latex or nitrile).
4. Remove protective backing from film.
5. Align film to surface and adhere one end in order to work end to end.
6. Smooth film from end to end, working in a linear motion to push air from under film, starting from the center toward the edge.

OPTIONAL:

7. Film can be further smoothed by placing the film liner over the Sharklet film and dragging a straight edge from one end to the other, further pushing bubbles towards the edges.